



VAPE BATTERY

INSTRUCTIONS

To turn vaporizer pen **ON/OFF**, click the button 5 times at a rapid pace

Click the button rapidly 3 times to change the **HEAT SETTING**



HIGH
3.6V



MEDIUM
3.1V



LOW
2.7V

To **CHARGE YOUR BATTERY** replace the cartridge with the provided USB charger and connect to any USB wall adapter

FIND THIS AND ALL OTHER FLUENT REFERENCE MATERIALS AVAILABLE FOR
DOWNLOAD AT GETFLUENT.COM/PAPERLESS

FLUENT
C A N N A B I S C A R E